



CP-48S P2 Bleach Fix Start Up Kit For Processing Fujicolor Papers and Equivalent Papers in Frontier Minilabs

Catalog Number: 600005483 (10 L)

DESCRIPTION

This product is designed for mixing fresh P2 bleach fix working tank solution for Fuji Frontier 330 & 390 minilab processors.

SAFE HANDLING INSTRUCTIONS

Please refer to Material Safety Data Sheets (MSDS) for specific chemical details. For emergencies, please contact CHEMTREC at 1-800-424-9300. You can obtain an MSDS by calling the Fujifilm Technical Hotline at 1-800-526-0851 Ext. 10.

HMIS INFORMATION

Hazardous Materials Identification System. Please refer to Section 3 in the MSDS for further information.

	Concentrate		Working Tank
	Part A	Part B	
Health	2	2	1
Flammability	0	0	0
Reactivity	0	0	0
Personal Protection	C	C	C

SPECS & RECOMMENDATIONS For Frontier 330/390

Temperature	38° ± 2.0° C 100.4° ± 3.6° F
Processing Time	P2 = 45"

Refer to bulletin 600005390/6000005482 for additional specifications and recommendations

MIXING INSTRUCTIONS

Fresh Bleach Fix Working Tank Frontier 330

P2W	Water	Concentrate		Top Off With Water
		Part A	Part B	
10 Liters	Pour 2L of water into the P2 circulation filter port	2 L Water (30-40° C) + 1 Bottle Part A	2 L Water (30-40° C) + 1 Bottle Part B	Set level gauge onto P2 circulation port. Add water up to the P2 line (Approx. 1.2 L)

Fresh Bleach Fix Working Tank Frontier 390

P2W	Water	Concentrate		Top Off With Water
		Part A	Part B	
10 Liters	Pour 2L of water into your mixing jug	2 L Water (30-40° C) + 1 Bottle Part A	2 L Water (30-40° C) + 1 Bottle Part B	Add water until mix is at the 10L line (Approx. 1.2 L) Add to P2-WT. Set level gauge onto P2 circulation port. Repeat until solution reaches P2 line (6 times)

SHELF LIFE

	Concentrate		Working Tank
	Part A	Part B	
Time	U = 24 Months O = 2 Weeks	U = 24 Months O = 2 Weeks	1 Week
Color	Clear, Dark Brown	Clear, Colorless	Clear, Pale Yellow
Odor	No Odor	Slight Ammonia Odor	Slight Ammonia Odor

U = Unopened, O = Opened

The data contained in this photographic bulletin is believed to be true and accurate, but is offered solely for your consideration, investigation, and verification. Nothing herein shall be construed to be a warranty or guarantee by either FUJIFILM Hunt Chemicals or any of its affiliates, and all such warranties, implied or otherwise, including any implied warranty of merchantability, are hereby expressly disclaimed. You, of course, are fully responsible for any use and / or domestic or foreign sale of the product(s) described, and nothing in this photographic bulletin shall be construed to constitute permission or a recommendation to practice any invention covered by patent or patent application or know-how owned by FUJIFILM, its affiliates, or others.