



CP-48S P1 Developer Start Up Kit For Processing Fujicolor Papers and Equivalent Papers in Frontier Minilabs

Catalog Number: 600005485 (10 L)

DESCRIPTION

This product is designed for mixing fresh P1 developer working tank solution for Fuji Frontier 330 & 390 minilab processors.

SAFE HANDLING INSTRUCTIONS

Please refer to Material Safety Data Sheets (MSDS) for specific chemical details. For emergencies, please contact CHEMTREC at 1-800-424-9300. You can obtain an MSDS by calling the Fujifilm Technical Hotline at 1-800-526-0851 Ext. 10.

HMIS INFORMATION

Hazardous Materials Identification System. Please refer to Section 3 in the MSDS for further information.

	Concentrate		Working Tank
	Part A	Part B	
Health	3	2	1
Flammability	0	0	0
Reactivity	0	0	0
Personal Protection	C	C	C

SPECS & RECOMMENDATIONS Frontier 330/390

Temperature	38.5° ± 0.3° C 101.3° ± 0.5° F
Processing Time	P1 = 45"

Refer to bulletin 600005390/600005482 for additional specifications and recommendations

MIXING INSTRUCTIONS

Fresh Developer Working Tank-Frontier 330

P1W	Water	Concentrate		Top Off With Water
		Part A	Part B	
10 Liters	Pour 2 liters of water into the P1 circulation filter port	1 L Water (30-40° C) + 1 Bottle Part A	2 L Water (30-40° C) + 1 Bottle Part B	Set level gauge onto P1 circulation port. Add water up to the P1 line (Approx. 2.2 L)

Fresh Developer Working Tank-Frontier 390

P1W	Water	Concentrate		Top Off With Water
		Part A	Part B	
10 Liters	Pour 2 liters of water into your mixing jug	1 L Water (30-40° C) + 1 Bottle Part A	2 L Water (30-40° C) + 1 Bottle Part B	Add water until mix is at 10L line (Approx. 2.2 L) Add to P1-WT. Set level gauge onto P1 circulation port. Repeat until solution reaches P1 line (6 times)

SHELF LIFE

	Concentrate		Working Tank
	Part A	Part B	
Time	U = 24 Months O = 2 Weeks	U = 24 Months O = 2 Weeks	2 Weeks
Color	Clear, Yellow	Clear, Colorless	Clear, Yellow
Odor	Slight Odor	Slight Odor	No Odor

U = Unopened, O = Opened

The data contained in this photographic bulletin is believed to be true and accurate, but is offered solely for your consideration, investigation, and verification. Nothing herein shall be construed to be a warranty or guarantee by either FUJIFILM Hunt Chemicals or any of its affiliates, and all such warranties, implied or otherwise, including any implied warranty of merchantability, are hereby expressly disclaimed. You, of course, are fully responsible for any use and / or domestic or foreign sale of the product(s) described, and nothing in this photographic bulletin shall be construed to constitute permission or a recommendation to practice any invention covered by patent or patent application or know-how owned by FUJIFILM, its affiliates, or others.