

FUJIFILM

PRODUCT INFORMATION BULLETIN

CP49E PC Cartridge Replenisher #60005393

OPERATING SPECIFICATIONS - FRONTIER 710

Temperature	P1	42° ± 0.3° C
	P2	40° ± 2.0° C
	P3	40° - 46° C
Processing Time	P1	22"
	P2	27"
	P3	172"
Starting Replenishment Rate	P1	45 ml/m ²
	P2	35 ml/m ²
	P3	215 ml/m ²

OPERATING SPECIFICATIONS - FRONTIER 770

Temperature	P1	42° ± 0.3° C
	P2	40° ± 2.0° C
	P3	40° - 46° C
Processing Time	P1	22"
	P2	22"
	P3	140"
Starting Replenishment Rate	P1	45 ml/m ²
	P2	35 ml/m ²
	P3	215 ml/m ²

OPERATING SPECIFICATIONS - FRONTIER 750

Temperature	P1	42° ± 0.3° C
	P2	40° ± 2.0° C
	P3	40° - 46° C
Processing Time	P1	28"
	P2	28"
	P3	180"
Starting Replenishment Rate	P1	45 ml/m ²
	P2	35 ml/m ²
	P3	215 ml/m ²

OPERATING SPECIFICATIONS - FRONTIER 790

Temperature	P1	42° ± 0.3° C
	P2	40° ± 2.0° C
	P3	40° - 46° C
Processing Time	P1	20"
	P2	20"
	P3	160"
Starting Replenishment Rate	P1	45 ml/m ²
	P2	35 ml/m ²
	P3	215 ml/m ²

PHYSICAL INFORMATION

	Concentrate			Working Tank	
	P1-R	P2-RA	P2-RB	P1-R	P2-R
Shelf Life Time	U=24 mos O= N/A	U=24 mos O= N/A	U=24 mos O= N/A	1 Week	1 Week
Color	Clear, Yellow	Clear, Dark Brown	Clear, Pale Yellow	Clear, Pale Yellow	Clear, Pale Yellow
Odor	No Odor	No Odor	Slight Ammonia	No Odor	Slight Ammonia

The data contained in this product information bulletin is offered solely for your consideration, investigation and verification. Nothing herein shall be construed to be a warranty or guarantee by either FUJIFILM U.S.A., INC. (FUJIFILM) or any of its affiliates of the information contained herein or of any products which such information relates, and ALL SUCH WARRANTIES, EXPRESS, IMPLIED OR OTHERWISE, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR USE, ARE HEREBY EXPRESSLY DISCLAIMED. You are fully responsible for any use and / or sale of the product(s) described, and nothing in this bulletin shall be construed to constitute permission or a recommendation to practice any invention covered by patent or patent application or know-how owned by FUJIFILM or others.